

Service Bulletin

Product Name	LinkIt Smart 7688 DUO	Part Number	102110017	Issued Date	02/26/2016
--------------	-----------------------	-------------	-----------	-------------	------------


instructions

How to burn in the firmware:
如何烧录固件

Copy the attached firmware into the USB drive, connect it to DUO board through OTG cable; power on the 7688 DUO board
将固件放置到U盘，并且通过OTG线连接到板。板子上电

1. Pus WIFI "reset" button
1. 按住 wifi reset button
2. Push and release MPU reset button on the same time
2. 同时按下並放開 mpu reset button
3. The Orange WIFI LED lights up, and goes out five seconds later; release WIFI reset button
3. 此時橘色 wifi LED 燈會亮起，五秒後看見 LED 燈熄滅時，放開 wifi reset button
4. Program then reads firmware from the USB drive, while WIFI LED flashes;
4. 接下來平台會開始從 usb 讀取 firmware 檔案與寫入更新，此時 會看見 wifi LED 燈號固定頻率地閃爍
5. Firmware update will be done three minutes later, 7688 DUO will restart while WIFI LED lights continually.
5. 約 3 分鐘更新寫入完成，系統會重新開機 (此時 WiFi LED 燈會 長亮)
6. Firmware update finishes after the WIFI LED light goes out.
6. 待 WiFi LED 燈滅時即完成更新

Flash Firmware from USB drive



Approved	<input checked="" type="checkbox"/>	Approved	Prepared by	Tang Yun Zhu	Date	02/26/2016
	<input type="checkbox"/>	Pending	Approved by	John Hong	Date	02/26/2016